

Selection Guide

Sivoia® QS Triathlon®

Residence: _____ Room: _____ Window(s): _____

Step 1 Select Shade Style


Honeycomb

Roller


Headrail without fascia

Fabric-wrapped fascia (regular roll only)

Roll orientation



Regular –
fabric closest
to the glass
(standard)



Reverse –
fabric farthest
from the glass.
Recommended
to clear door or
window hardware.

Step 2 Select Power

Battery-powered

Plug-in

Power
Panel

Manual
shade

Step 3 Select Control

System

Keypad

Timeclock

Mobile
device

Third-party
integration

Pico®

Standalone

Pico® –
for controlling a single
shade or multiple shades
with one button press.

4-group RF –
for assigning a group
of shades to each of
the four group buttons
on the remote.

Please note: Product options may vary depending on application and intended use. For more technical information, reference www.lutron.com or work with your qualified Lutron provider. Product availability is subject to change.

Step 4


Shade Mount and Measurements (choose one)

Inside Mount

Roller shade


With Fascia

Fully Recessed




Without Fascia

Fully Recessed




Honeycomb shade

Fully Recessed




Please note: For partial recess, the location of the mounting screw is 0.5" (13 mm) in from the back of the bracket for roller shades and .75" (19 mm) for honeycomb shades.

Width:



Smallest width: _____ inches/mm

Height:



Largest height: _____ inches/mm

Outside Mount on Trim

Width: The width of your shades can be as wide as you want, depending on what you want the fabric to cover.

Width: _____ inches/mm

Outside Mount above Trim (includes spacers)

Height: Measure from the top of the headrail to the windowsill.

Height: _____ inches/mm

Note: If mounting above the trim, we recommend allowing for at least 3 1/8" (80 mm) for honeycomb, 4.5" (114 mm) for roller, of space above the top edge of the window trim for the shade brackets.

Step 5

Select Fabric

Utilize the insulating Honeycomb or Roller Essentials fabric binder or visit www.lutron.com/fabrics

Fabric P/N: _____

For more information, please download The Lutron Fabric Collections mobile app at the Apple® store.

Step 6

Honeycomb Shade Enhancements

Back Cover

A back cover on the back of the headrail eliminates any light that may come through the mounting area (usually only used on room darkening, inside mount applications).

Cable-Guided

(outside mount only)

Select this if you are mounting a shade to a door.

Choose anchor and matching hardware color:




Snow



Biscuit



Sienna



For more information, please visit www.lutron.com or call **1(800) 446-1503**

www.lutron.com



World Headquarters 1.610.282.3800
24/7 Technical Support 1.800.523.9466
Customer Service 1.888.LUTRON1 (1.888.588.7661)



© 09/2013 Lutron Electronics Co., Inc. | P/N 367-2243 REV H

